



# CA Tech 2.5 Gallon Pressure Tanks Stainless - Bottom Outlet - Agitated



## CLICK-N-PICK SPARE PARTS CUTSHEET

C.A.Technol

Easily find spare parts without digging through the full manual. Click on part numbers to order.





WÂGNER



ENHANCED \*INTERACTIVE\* MANUAL

BLUE TEXT = CLICK TO ORDER 🖤

### 2.5 GALLON SS (NON-ASME)

STAINLESS STEEL AIR AGITATED BOTTOM OUTLET PRESSURE TANK PRODUCT INFORMATION



Coating Atomization Technologies 337 South Arthur Avenue, Louisville CO 80027 Phone: 888.820.4498, Fax: 303.438.5708 www.spraycat.com

#### **IMPORTANT NOTE:** IF THIS PRESSURE TANK IS TO BE USED FOR SPRAYING FLAMMABLE MATERIALS, OPERATOR MUST NOT PRESSURIZE THIS TANK MORE THAN 15 PSI TO MEET OSHA REQUIREMENTS. FOR NON-ASME PRESSURE VESSELS. IT IS THE RESPONSIBILITY OF THE OPERATOR TO FOLLOW THIS MANDATORY PROCEDURE.

#### **GENERAL INFORMATION**

This pressure tank is equipped with either single or double air pressure regulation, pressure safety relief valve, tank vent valve, bottom outlet ball valve, four caster wheels and air powered agitator.

- 1. Turn regulators to zero. Close ball valves. Turn agitator knob to off position. Fill tank with product and tighten down lid with wrench provided.
- 2. With air from compressor on, open ball valves. Adjust pot pressure as needed to flow material to gun.
- 3. Adjust gun regulator if provided, to atomize material as needed.
- 4. Adjust agitator knob to the slowest speed that mixes the material as needed.

#### CAUTION!

- 1. Maximum tank pressure of 80 psi. The safety relief valve is designed to protect the tank against excessive pressures. DO NOT attempt to make adjustments to this valve. If this valve begins to vent air, reduce the setting on the air inlet regulator.
- 2. DO NOT alter the tank in any way by welding, drilling or machining as this may weaken the structure of the tank.
- 3. To prevent hazardous static sparks from occurring, always ground the tank by connecting a 12 ga. wire to the tank and to a known earth ground.
- 4. Be sure tank pressure is completely relieved before attempting to remove tank cover or material fill cap. Shut off the main air supply to the tank and vent pressure using the vent valve located on the tank lid.

| **NOTE** Oiless Motor Used on CAT Agitated Tanks | DO NOT OIL TANK MOTORS |
|--|------------------------|
|  |                        |

| tem no. | PART NO. | DESCRIPTION                        | ITEM NO. | PART NO. | DESCRIPTION                  |
|---------|----------|------------------------------------|----------|----------|------------------------------|
| 1       | 51-278SS | Tank Shell                         | 18       | 51-238SS | Guard                        |
| 2       | 51-220   | Gasket (51-220-3 = 3 Pack)         | 19       | 98-0115  | Nut 3/8-16                   |
| 3       | 51-279SS | Tank Lid Assembly                  | 20       | 51-240SS | Air Motor                    |
| 4       | 51-229   | Safety Relief Valve Assembly       | 21       | 51-271   | Muffler                      |
| 5       | 51-234   | Tank Vent Valve                    | 22       | 51-262   | Set Screw 1/4-20 x 1" lg.    |
| 6       | 51-280   | Sw ivel Connection                 | 23       | 51-266   | Roll Pin                     |
| 7       | 52-10A   | Fluid Regulator Assembly           | 24       | 51-242   | Coupling                     |
| 8       | 52-11A   | Atomizing Air Regulator Assembly   | 25       | 51-288   | Guide                        |
| 9       | 52-58    | Pressure Gauge                     | 26       | 51-289   | Shaft Seal Assembly          |
| 10      | 52-303   | Dual Regulator Assembly            | 27       | 51-264   | Screw & Nut 1/4-20 x 1/4 lg. |
| 11      | 51-237   | Air Flow Diffuser                  | 28       | 51-287SS | Air Motor Base               |
| 12      | 51-236   | Eye Bolt Assembly                  | 29       | 51-245   | Seal Ring                    |
| 13      | 51-224   | Caster (4 Req'd)                   | 30       | 51-272   | 3-Way Union                  |
|         | 51-252   | Optional Stationary Feet (4 Req'd) | 31       | 51-239   | Double Male Nipple           |
| 14      | 51-233   | Pin Assembly                       | 32       | 51-247   | Speed Valve Control Assembly |
| 15      | 51-275SS | Fluid Outlet Elbow                 | 33       | 51-276SS | Agitator Shaft               |
| 16      | 51-274SS | Fluid Outlet Ball Valve            | 34       | 51-259SS | Retaining Nut                |
| 17      | 51-225   | Wrench                             | 35       | 51-246   | Propeller W/Bolt             |

Note: (1) 98-0383 & (1) 53-555 are needed to adapt a standard 3/8" fluid hose fitting to the bottom outlet ball valve.

Single regulated supplied with item 7, double regulated supplied with items 7 & 8





Revised 11/13/15